



# **TLR6600 TELEHANDLER PARTS MANUAL**



**[www.fliftamerica.com](http://www.fliftamerica.com)**

---



**NOTE:** *This parts manual identifies both standard and optional features for this model. Depending on the features of your machine, some of the items identified in the parts lists may, or may not be included with the machine.*

The Table of Contents pages list the page locations of various component groups on the machine.

When ordering service parts, specify the part number, full description, quantity required, and the unit model and serial number.

Model and serial numbers for this unit are stamped on a plate located cab inside the operator’s station. The serial number is also stamped on the left front of the frame. The following reference shows the breakdown of the serial number:

“Right” and “left” are determined from a position standing behind the unit and facing the direction of forward travel.

FLIFT forklift manufacturer reserves the right to make changes or improvements in the design or construction of any part of the unit without incurring the obligation to install such changes on any unit previously delivered.

Grease fittings and common attaching hardware, such as cotter pins, set screws, woodruff keys, screws and nuts are included in the parts list, indented below the part they are associated with, but NOT illustrated, except where a particular routing or special fastening arrangement must be maintained. The hardware listed is for mounting purposes and is NOT included when the part is ordered for replacement.



In cab



Front left


## INDEX

|                                  | Page |
|----------------------------------|------|
| Filters.....                     | 1    |
| Standard Cab.....                | 10   |
| Cab rear glass.....              | 11   |
| Cab wiper.....                   | 12   |
| Cab dash board.....              | 13   |
| Accelerator pedal.....           | 14   |
| Hand brake.....                  | 17   |
| Steering wheel assembly.....     | 18   |
| Joystick assembly.....           | 22   |
| Seat assembly.....               | 23   |
| Relay box.....                   | 25   |
| A/C parts.....                   | 26   |
| Heater circuit.....              | 27   |
| Fuel tank.....                   | 28   |
| Cab damper rubber block.....     | 30   |
| The pins.....                    | 31   |
| Battery & Machine rear side..... | 32   |
| Tow hook & rear side.....        | 33   |
| Priority valve hydraulic.....    | 34   |
| Steer select valve.....          | 36   |
| Select valve.....                | 37   |
| Joy stick oil supply valve.....  | 38   |


|                                      |    |
|--------------------------------------|----|
| Joy stick valve.....                 | 41 |
| Main valve.....                      | 42 |
| Transmission & pumps.....            | 45 |
| Transmission torque converter.....   | 55 |
| Radiator assembly.....               | 60 |
| Air compressor system.....           | 63 |
| Engine flame-out motor.....          | 65 |
| Transmission shaft.....              | 66 |
| Axle.....                            | 68 |
| Axle differential mechanism.....     | 70 |
| Tyre & rim.....                      | 72 |
| Lifting cylinder.....                | 73 |
| Extend retract cylinder.....         | 75 |
| Tilt cylinder.....                   | 77 |
| Slave cylinder.....                  | 79 |
| Quick hitch cylinder.....            | 81 |
| Quick joint.....                     | 83 |
| Boom outer.....                      | 84 |
| Boom inner.....                      | 85 |
| Standard type quick hitch.....       | 86 |
| D type quick hitch.....              | 87 |
| The air bag.....                     | 88 |
| The mirror and mirror bracket.....   | 89 |
| Splash guard and bracket.....        | 90 |
| Muffler (For Yuchai and Yunnei)..... | 91 |
| Muffler(For CUMMINS).....            | 92 |



***For Yunnei / Yuchai brand and Yanmar engine***




| Ref. | Part         | Description                       | Qty. |     |             |                                               |  |
|------|--------------|-----------------------------------|------|-----|-------------|-----------------------------------------------|--|
| No.  | No.          |                                   |      | No. | No.         |                                               |  |
| 01   | KL 1522F     | AIR FILTER ASSEMBLY               |      | 01  | KL1204      | For Xinchai Emission V engine 55.8kw use only |  |
| 02   | K11900CD     | AIR FILTER                        |      | 02  | KJAC-1204   | For Xinchai Emission V engine 55.8kw use only |  |
| 03   | KL 1522F C1  | AIR FILTER BOTTOM COVER           |      | 03  | KL 1204 C1  | For Xinchai Emission V engine 55.8kw use only |  |
| 04   | KL 1522F NC1 | AIR FILTER INNER DUST PROOF COVER |      | 04  | KL 1204 NC1 | For Xinchai Emission V engine 55.8kw use only |  |
| 05   | KL 1522F C2  | AIR FILTER TOP COVER              |      | 05  | KL 1204 C2  | For Xinchai Emission V engine 55.8kw use only |  |




| Ref. | Part         | Description                       | Qty. |  |  |  |  |
|------|--------------|-----------------------------------|------|--|--|--|--|
| No.  | No.          |                                   |      |  |  |  |  |
| 01   | KW1833X-K02X | AIR FILTER ASSEMBLY               |      |  |  |  |  |
| 02   | 1833F O      | AIR FILTER (outside)              |      |  |  |  |  |
| 03   | 1833F I      | AIR FILTER (inside)               |      |  |  |  |  |
| 04   | KW1833X C1   | AIR FILTER INNER DUST PROOF COVER |      |  |  |  |  |
| 05   | KW1833X C2   | AIR FILTER TOP COVER              |      |  |  |  |  |



| Ref. | Part   | Description          | Qty. |                |                                             |  |  |
|------|--------|----------------------|------|----------------|---------------------------------------------|--|--|
| No.  | No.    |                      |      |                |                                             |  |  |
| 01   | CX0708 | Engine diesel filter | 01   | 4E30RG40-24120 | For Xinchai Emission V Engine Diesel filter |  |  |
| 02   | JX0810 | Engine oil filter    | 02   | JC840ZX1       | For Xinchai Emission V Engine oil filter    |  |  |




| Ref. | Part   | Description                             | Qty. |  |  |  |  |
|------|--------|-----------------------------------------|------|--|--|--|--|
| No.  | No.    |                                         |      |  |  |  |  |
| 01   | FS1280 | Engine diesel - water separation filter |      |  |  |  |  |
| 02   | FF5052 | Engine diesel filter                    |      |  |  |  |  |
| 03   | LF3345 | Engine oil filter                       |      |  |  |  |  |




| Ref. | Part      | Description        | Qty. |  |  |  |  |
|------|-----------|--------------------|------|--|--|--|--|
| No.  | No.       |                    |      |  |  |  |  |
| 01   | FD01-6735 | Diesel tank filter |      |  |  |  |  |







| Ref. | Part     | Description               | Qty. |  |  |  |  |
|------|----------|---------------------------|------|--|--|--|--|
| No.  | No.      |                           |      |  |  |  |  |
| 01   | FW17670A | Main pump filter assembly |      |  |  |  |  |
| 02   | FW17670  | Main pump filter          |      |  |  |  |  |




| Ref. | Part     | Description                       | Qty. |  |  |  |  |
|------|----------|-----------------------------------|------|--|--|--|--|
| No.  | No.      |                                   |      |  |  |  |  |
| 01   | FW17671A | Transmission Main filter assembly |      |  |  |  |  |
| 02   | FW17671  | Transmission Main filter          |      |  |  |  |  |




| Ref. | Part     | Description                                              | Qty. |  |  |  |  |
|------|----------|----------------------------------------------------------|------|--|--|--|--|
| No.  | No.      |                                                          |      |  |  |  |  |
| 01   | FJ13040A | Transmission electric valve first filter assembly(16-16) |      |  |  |  |  |
| 02   | FJ13040  | Transmission electric valve first filter                 |      |  |  |  |  |
| 03   | FJ13041  | Transmission electric valve second filter                |      |  |  |  |  |




| Ref. | Part     | Description                             | Qty. |  |  |  |  |
|------|----------|-----------------------------------------|------|--|--|--|--|
| No.  | No.      |                                         |      |  |  |  |  |
| 01   | FJ13041A | Joystick oil filter assembly<br>(14-14) |      |  |  |  |  |
| 02   | FJ13040  | Joystick oil filter                     |      |  |  |  |  |



| Ref. | Part   | Description             | Qty. | Ref.                         | Part   | Description                                                   | Qty. |
|------|--------|-------------------------|------|------------------------------|--------|---------------------------------------------------------------|------|
| No.  | No.    |                         | Req. | No.                          | No.    |                                                               | Req. |
| 01   | 808101 | Front glass             |      | 09                           | 838101 | Cab rear working light 12v-24v ( USE ON Cab front light also) |      |
| 02   | 808102 | Door glass 1            |      | 10                           | 808110 | Door open position Locker (assembly)                          |      |
| 03   | 808103 | Door glass 2            |      | 11                           | 808111 | Door locker (assembly)                                        |      |
| 04   | 808104 | Left glass              |      | 12                           | 808112 | Cab lifting bolt ring                                         |      |
| 05   | 808105 | Rear glass              |      | 13                           | 808113 | FOPS (assembly)                                               |      |
| 06   | 808106 | Right glass             |      | 14                           | 808114 | Left front mirror support                                     |      |
| 07   | 808107 | Top glass               |      | 15                           | 808115 | Left front mirror                                             |      |
| 08   | 838101 | Cab front light 12v-24v |      | <b>-- ITEMS NOT SHOWN --</b> |        |                                                               |      |




| Ref. | Part   | Description                            | Qty. |  |  |  |  |
|------|--------|----------------------------------------|------|--|--|--|--|
| No.  | No.    |                                        |      |  |  |  |  |
| 01   | 808116 | Cab rear glass air cylinder (assembly) |      |  |  |  |  |
| 02   | 808117 | Rear glass locker (assembly)           |      |  |  |  |  |
| 03   | 808118 | Plastic screw                          |      |  |  |  |  |
| 04   | 808119 | Rear glass hinge (assembly)            |      |  |  |  |  |
| 05   | 808120 | Rear glass handler LEFT                |      |  |  |  |  |
| 06   | 808121 | Rear glass handler RIGHT               |      |  |  |  |  |




| Ref. | Part   | Description            | Qty. |  |  |  |  |
|------|--------|------------------------|------|--|--|--|--|
| No.  | No.    |                        |      |  |  |  |  |
| 01   | 838133 | Wiper motor (assembly) |      |  |  |  |  |
| 02   | 808123 | Wiper blade (assembly) |      |  |  |  |  |







| Ref. | Part   | Description                             | Qty. |          |                       |  |  |
|------|--------|-----------------------------------------|------|----------|-----------------------|--|--|
| No.  | No.    |                                         |      |          |                       |  |  |
| 01   | 808124 | Dash board                              |      |          |                       |  |  |
| 02   | 838102 | Moment limiter display<br>(Option part) | 04   | 838102-1 | Moment limiter sensor |  |  |
| 03   | 838103 | Cigarette lighter                       |      |          |                       |  |  |




| Ref. | Part   | Description                          | Qty. |  |  |  |  |
|------|--------|--------------------------------------|------|--|--|--|--|
| No.  | No.    |                                      |      |  |  |  |  |
| 01   | 838349 | Brake pedal & brake valve (assembly) |      |  |  |  |  |
| 02   | 838104 | Brake light air pressure switch      |      |  |  |  |  |




| Ref. | Part   | Description                           | Qty. |  |  |  |  |
|------|--------|---------------------------------------|------|--|--|--|--|
| No.  | No.    |                                       |      |  |  |  |  |
| 01   | 838105 | Electric accelerator pedal (assembly) |      |  |  |  |  |
|      |        |                                       |      |  |  |  |  |




| Ref. | Part   | Description            | Qty. |  |  |  |  |
|------|--------|------------------------|------|--|--|--|--|
| No.  | No.    |                        |      |  |  |  |  |
| 01   | 808125 | Accelerator pedal      |      |  |  |  |  |
| 02   | 808126 | Accelerator pedal base |      |  |  |  |  |
| 03   | 808127 | Accelerator cable      |      |  |  |  |  |



| Ref. | Part   | Description      | Qty. |  |  |  |  |
|------|--------|------------------|------|--|--|--|--|
| No.  | No.    |                  |      |  |  |  |  |
| 01   | 808128 | Hand brake       |      |  |  |  |  |
| 02   | 808129 | Hand brake cable |      |  |  |  |  |
|      |        |                  |      |  |  |  |  |




| Ref. | Part   | Description                     | Qty. |  |  |  |  |
|------|--------|---------------------------------|------|--|--|--|--|
| No.  | No.    |                                 |      |  |  |  |  |
| 01   | 828001 | Steering wheel                  |      |  |  |  |  |
| 02   | 838106 | Electric F-N-R selection switch |      |  |  |  |  |
| 03   | 838335 | Steering valve                  |      |  |  |  |  |




| Ref. | Part   | Description                 | Qty. | Ref. | Part   | Description          |  |
|------|--------|-----------------------------|------|------|--------|----------------------|--|
| No.  | No.    |                             |      | No.  | No.    |                      |  |
| 01   | 828002 | Air pressure gauge          |      | 04   | 808001 | Steering wheel base  |  |
| 02   | 828003 | Transmission pressure gauge |      | 05   | 828005 | Steering wheel shell |  |
| 03   | 828004 | Steering column assembly    |      |      |        |                      |  |






| Ref. | Part   | Description                  | Qty. | Ref. | Part | Description |  |
|------|--------|------------------------------|------|------|------|-------------|--|
| No.  | No.    |                              |      | No.  | No.  |             |  |
| 01   | 828006 | LCD display assembly         |      |      |      |             |  |
| 02   | 838107 | Turn indicator control stick |      |      |      |             |  |
| 03   | 828007 | Ignition switch              |      |      |      |             |  |







| Ref. | Part   | Description                       | Qty. | Ref. | Part   | Description                                     |  |
|------|--------|-----------------------------------|------|------|--------|-------------------------------------------------|--|
| No.  | No.    |                                   |      | No.  | No.    |                                                 |  |
| 01   | 838108 | Danger signal light rocker switch |      | 06   | 838113 | First and second gear rocker switch             |  |
| 02   | 838109 | Rear light rocker switch          |      | 07   | 838114 | Fuse base                                       |  |
| 03   | 838110 | Front light rocker switch         |      | 08   | 838115 | Fuse (Function info. refer to operation manual) |  |
| 04   | 838111 | Windscreen wiper rocker switch    |      | 09   | 838116 | Flash relay                                     |  |
| 05   | 838112 | Fan and heater rocker switch      |      | 10   | 838117 | Engine preheat relay                            |  |




| Ref. | Part   | Description                     | Qty. | Ref. | Part   | Description                 |  |
|------|--------|---------------------------------|------|------|--------|-----------------------------|--|
| No.  | No.    |                                 |      | No.  | No.    |                             |  |
| 01   | 808130 | Joystick shell (Without button) |      | 04   | 838118 | Joystick button (One piece) |  |
| 02   | 838303 | Joystick pilot control valve    |      | 05   | 838119 | Steering selection switch   |  |
| 03   | 808131 | Joystick box                    |      | 06   | 838120 | Steering ECU assembly       |  |




| Ref. | Part   | Description          | Qty. | Ref. | Part   | Description             |
|------|--------|----------------------|------|------|--------|-------------------------|
| No.  | No.    |                      |      | No.  | No.    |                         |
| 01   | 808132 | Seat assembly        |      | 04   | 838121 | Cab Heater (Standard)   |
| 02   | 808133 | Suspension seat base |      | 04   | 838122 | A/C evaporator (Option) |
| 03   | 808002 | Seat base            |      | 05   | 808134 | Seat belt assembly      |




| Ref. | Part   | Description           | Qty. |  |  |  |  |
|------|--------|-----------------------|------|--|--|--|--|
| No.  | No.    |                       |      |  |  |  |  |
| 01   | 808135 | Cab carpet (assembly) |      |  |  |  |  |
|      |        |                       |      |  |  |  |  |



| Ref. | Part   | Description                                              | Qty. | Ref. | Part   | Description |  |
|------|--------|----------------------------------------------------------|------|------|--------|-------------|--|
| No.  | No.    |                                                          |      | No.  | No.    |             |  |
| 01   | 838123 | 12V-24V relay (Function info. refer to operation manual) |      | 04   | 838126 | Relay box   |  |
| 02   | 838124 | Relay base "X" type                                      |      |      |        |             |  |
| 03   | 838125 | Relay base "S" type                                      |      |      |        |             |  |




| Ref. | Part   | Description             | Qty. | Ref. | Part   | Description             |  |
|------|--------|-------------------------|------|------|--------|-------------------------|--|
| No.  | No.    |                         |      | No.  | No.    |                         |  |
| 01   | 838300 | A/C Compressor (Option) |      | 04   | 838122 | A/C evaporator (Option) |  |
| 02   | 811702 | A/C Condenser           |      |      |        |                         |  |
| 03   | 811703 | A/C dryer can           |      |      |        |                         |  |




| Ref. | Part   | Description                  | Qty. | Ref. | Part   | Description        |  |
|------|--------|------------------------------|------|------|--------|--------------------|--|
| No.  | No.    |                              |      | No.  | No.    |                    |  |
| 01   | 838121 | Cabin Heater 12V-24V         |      | 04   | 811704 | Heater rubber tube |  |
| 02   | 838306 | Heater engine side valve     |      |      |        |                    |  |
| 03   | 838307 | Heater engine side iron pipe |      |      |        |                    |  |






| Ref. | Part   | Description                    | Qty. | Ref.          | Part              | Description                  |  |
|------|--------|--------------------------------|------|---------------|-------------------|------------------------------|--|
| No.  | No.    |                                |      | No.           | No.               |                              |  |
| 01   | 806101 | Fuel and hydraulic tank cap    |      | <del>08</del> | <del>806105</del> | <del>Tank O ring "C"</del>   |  |
| 02   | 808003 | Hydraulic tank fill pipe       |      | 09            | 838127            | Electric diesel height gauge |  |
| 03   | 808004 | Diesel tank fill pipe          |      | 10            | 808006            | Diesel tank top flange plate |  |
| 04   | 806102 | Tank O ring "A"                |      | 11            | 806138            | Hose                         |  |
| 05   | 806103 | Hydraulic tank window assembly |      | 12            | 861403            | T-Junction                   |  |
| 06   | 806104 | Tank O ring "B"                |      | 13            | 806139            | Hose                         |  |
| 07   | 808005 | Tank flange plate              |      | 14            |                   |                              |  |







| Ref. | Part   | Description | Qty. | Ref. | Part | Description |  |
|------|--------|-------------|------|------|------|-------------|--|
| No.  | No.    |             |      | No.  | No.  |             |  |
| 01   | 806140 | Hose        |      |      |      |             |  |
| 02   | 806141 | Hose        |      |      |      |             |  |
|      |        |             |      |      |      |             |  |




| Ref. | Part   | Description             | Qty. | Ref. | Part | Description |  |
|------|--------|-------------------------|------|------|------|-------------|--|
| No.  | No.    |                         |      | No.  | No.  |             |  |
| 01   | 806106 | Cab damper rubber block |      |      |      |             |  |
| 02   | 806107 | Cab side rubber block   |      |      |      |             |  |
|      |        |                         |      |      |      |             |  |




| Ref. | Part   | Description                  | Qty. | Ref. | Part   | Description                   |  |
|------|--------|------------------------------|------|------|--------|-------------------------------|--|
| No.  | No.    |                              |      | No.  | No.    |                               |  |
| 01   | 808010 | Telescopic cylinder Rear Pin |      | 07   | 808016 | Lifting cylinder Front Pin    |  |
| 02   | 808011 | Boom Main Pin                |      | 08   | 808017 | Telescopic cylinder Front Pin |  |
| 03   | 808012 | Balance cylinder Rear Pin    |      | 09   | 808018 | Dump cylinder Rear Pin        |  |
| 04   | 808013 | Rear Axle Pin                |      | 10   | 808019 | Carriage main pin             |  |
| 05   | 808014 | Lifting cylinder Rear Pin    |      | 11   | 808020 | Dump cylinder Front pin       |  |
| 06   | 808015 | Balance cylinder Front Pin   |      | 12   | 808021 | Quick hitch lock pin          |  |




| Ref. | Part   | Description                    | Qty. | Ref. | Part   | Description                   |  |
|------|--------|--------------------------------|------|------|--------|-------------------------------|--|
| No.  | No.    |                                |      | No.  | No.    |                               |  |
| 01   | 838128 | Electromagnetic switch 12V-24V |      | 07   | 808026 | Battery fixed screw rod       |  |
| 02   | 808022 | Rear Signal light left frame   |      | 08   | 838130 | Battery (12V 80ah)            |  |
| 03   | 838129 | Rear Signal light Left         |      | 09   | 808027 | Rear Signal light right frame |  |
| 04   | 808023 | Rear battery side top cover    |      | 10   | 838131 | Rear Signal light Right       |  |
| 05   | 808024 | Rear side bottom cover         |      | 11   | 838132 | Reversing buzzer              |  |
| 06   | 808025 | Battery fixed support          |      |      |        |                               |  |



| Ref. | Part    | Description                       | Qty. | Ref. | Part     | Description            |  |
|------|---------|-----------------------------------|------|------|----------|------------------------|--|
| No.  | No.     |                                   |      | No.  | No.      |                        |  |
| 01   | 808028  | Rear multi-function Plate         |      | 07   | 86121815 | ADAP-ZG1/2-18*1.5H     |  |
| 02   | 838133  | 7 pins Trailer socket (Option)    |      | 08   | 806109   | Rear air pressure hose |  |
| 03   | 858002  | High pressure air outlet coupling |      | 09   | 808029   | Towing Pin             |  |
| 04   | 818101  | M10 Straight type grease fitting  |      | 10   | 818105   | Spring pin             |  |
| 05   | 8181142 | M14 Thin nut                      |      | 11   | 808030   | Towing hook            |  |
| 06   | 806108  | Grease pipe for rear axle         |      |      |          |                        |  |




| Ref. | Part     | Description             | Qty. | Ref. | Part       | Description       |  |
|------|----------|-------------------------|------|------|------------|-------------------|--|
| No.  | No.      |                         |      | No.  | No.        |                   |  |
| 01   | 808031   | Multifunction supportor |      | 07   | 861214     | ADAP              |  |
| 02   | 806110   | Hose                    |      | 08   | 806116     | Hose              |  |
| 03   | 806111   | Hose                    |      | 09   | 861214     | ADAP              |  |
| 04   | 862218   | ADAP                    |      | 10   | 806115     | Hose              |  |
| 05   | 8627-230 | ADAP                    |      | 11   | 8627-227-2 | ADAP              |  |
| 06   | 838311   | Priority valve          |      | 12   | 838317     | Pilot check valve |  |



| Ref. | Part      | Description | Qty. | Ref. | Part   | Description                    |  |
|------|-----------|-------------|------|------|--------|--------------------------------|--|
| No.  | No.       |             |      | No.  | No.    |                                |  |
| 13   | 8627-236  | ADAP        |      | 16   | 838308 | Hydraulic pressure check joint |  |
| 14   | 806120    | Hose        |      | 17   | 863618 | ADAP                           |  |
| 15   | 7888CC-36 | T-Junction  |      | 18   | 806122 | Hose                           |  |







| Ref. | Part   | Description                      | Qty. | Ref. | Part   | Description  |  |
|------|--------|----------------------------------|------|------|--------|--------------|--|
| No.  | No.    |                                  |      | No.  | No.    |              |  |
| 01   | 838240 | Steer select valve assembly(12v) |      | 09   | 806124 | Hose         |  |
|      | 838241 | Steer select valve assembly(24v) |      |      |        |              |  |
| 02   | 838212 | Valve controller switch (12V)    |      | 10   | 862218 | ADAP         |  |
|      | 838214 | Valve controller switch (24V)    |      |      |        |              |  |
| 03   | 838222 | Valve Solenoid coil (12V)        |      | 11   | 862218 | ADAP         |  |
|      | 838224 | Valve Solenoid coil (24V)        |      |      |        |              |  |
| 04   | 838201 | Select valve body                |      | 12   | 862218 | ADAP         |  |
| 05   | 838202 | Valve electromagnet body         |      | 13   | 806125 | Hose         |  |
| 06   | 838203 | Steer Valve connector with cable |      | 14   | 862218 | ADAP         |  |
| 07   | 838250 | Steer Valve D10 valve body       |      | 15   | 806126 | Hose         |  |
| 08   | 806123 | Hose                             |      | 16   | 860022 | Screwed plug |  |




Select valve




| Ref. | Part   | Description                   | Qty. | Ref. | Part   | Description |  |
|------|--------|-------------------------------|------|------|--------|-------------|--|
| No.  | No.    |                               |      | No.  | No.    |             |  |
| 01   | 808032 | Front first cover             |      | 09   | 806128 | Hose        |  |
| 02   | 838232 | Valve controller switch (12V) |      | 10   | 806129 | Hose        |  |
|      | 838234 | Valve controller switch (24V) |      |      |        |             |  |
| 03   | 838242 | Valve Solenoid coil (12V)     |      | 11   | 806130 | Hose        |  |
|      | 838244 | Valve Solenoid coil (24V)     |      |      |        |             |  |
| 04   | 838204 | Select Valve D7 valve body    |      | 12   | 806131 | Hose        |  |
| 05   | 838205 | Select valve body             |      | 13   | 806132 | Hose        |  |
| 06   | 838252 | Select valve assembly(12v)    |      | 14   | 862233 | Hose        |  |
|      | 838254 | Select valve assembly(24v)    |      |      |        |             |  |
| 07   | 861814 | ADAP                          |      | 15   | 806134 | Hose        |  |
| 08   | 806127 | Hose                          |      |      |        |             |  |




| Ref. | Part   | Description                | Qty. | Ref. | Part   | Description |  |
|------|--------|----------------------------|------|------|--------|-------------|--|
| No.  | No.    |                            |      | No.  | No.    |             |  |
| 01   | 838309 | Joy stick oil supply valve |      | 07   | 806135 | Hose        |  |
| 02   | 838310 | Manifold block             |      | 08   | 806134 | Hose        |  |
| 03   | 838135 | Electronic sensor          |      | 09   | 806135 | Hose        |  |
| 04   | 861403 | T-Junction                 |      | 10   | 806129 | Hose        |  |
| 05   | 801418 | ADAP                       |      | 11   | 806137 | Hose        |  |
| 06   | 801414 | ADAP                       |      | 12   | 806132 | ADAP        |  |



| Ref. | Part   | Description | Qty. | Ref. | Part   | Description |  |
|------|--------|-------------|------|------|--------|-------------|--|
| No.  | No.    |             |      | No.  | No.    |             |  |
| 13   | 806127 | Hose        |      | 17   | 806121 | Hose        |  |
| 14   | 806136 | Hose        |      | 18   | 806115 | Hose        |  |
| 15   | 806122 | Hose        |      | 19   | 806138 | Hose        |  |
| 16   | 801814 | ADAP        |      |      |        |             |  |




| Ref. | Part     | Description                          | Qty. | Ref. | Part | Description |  |
|------|----------|--------------------------------------|------|------|------|-------------|--|
| No.  | No.      |                                      |      | No.  | No.  |             |  |
| 01   | FJ13041A | Joystick oil filter assembly (14-14) |      |      |      |             |  |
| 02   | 806136   | Hose                                 |      |      |      |             |  |
| 03   | 806137   | Hose                                 |      |      |      |             |  |




| Ref. | Part    | Description | Qty. | Ref. | Part   | Description |  |
|------|---------|-------------|------|------|--------|-------------|--|
| No.  | No.     |             |      | No.  | No.    |             |  |
| 01   | 80G1414 | ADAP        |      | 05   | 806121 | Hose        |  |
| 02   | 806166  | Hose        |      | 06   | 806167 | Hose        |  |
| 03   | 806165  | Hose        |      | 07   | 806164 | Hose        |  |
| 04   | 806139  | Hose        |      |      |        |             |  |






| Ref. | Part     | Description | Qty. | Ref. | Part   | Description |  |
|------|----------|-------------|------|------|--------|-------------|--|
| No.  | No.      |             |      | No.  | No.    |             |  |
| 01   | 806156   | Hose        |      | 07   | 806161 | Hose        |  |
| 02   | 806157   | Hose        |      | 08   | 806162 | Hose        |  |
| 03   | 806158   | Hose        |      | 09   | 806163 | Hose        |  |
| 04   | 806159   | Hose        |      | 10   | 838302 | Main valve  |  |
| 05   | 8627-222 | ADAP        |      | 11   | 861414 | ADAP        |  |
| 06   | 806160   | Hose        |      | 12   | 862233 | Hose        |  |





| Ref. | Part   | Description | Qty. | Ref. | Part   | Description |  |
|------|--------|-------------|------|------|--------|-------------|--|
| No.  | No.    |             |      | No.  | No.    |             |  |
| 13   | 806130 | Hose        |      | 19   | 806166 | Hose        |  |
| 14   | 806164 | Hose        |      |      |        |             |  |
| 15   | 806165 | Hose        |      |      |        |             |  |
| 16   | 806128 | Hose        |      |      |        |             |  |
| 17   | 806131 | Hose        |      |      |        |             |  |
| 18   | 806167 | Hose        |      |      |        |             |  |






| Ref. | Part     | Description | Qty. | Ref. | Part   | Description |  |
|------|----------|-------------|------|------|--------|-------------|--|
| No.  | No.      |             |      | No.  | No.    |             |  |
| 01   | 8627-230 | ADAP        |      | 03   | 806111 | Hose        |  |
| 02   | 8627-236 | ADAP        |      | 04   | 806168 | Hose        |  |






| Ref. | Part   | Description       | Qty. | Ref. | Part   | Description  |  |
|------|--------|-------------------|------|------|--------|--------------|--|
| No.  | No.    |                   |      | No.  | No.    |              |  |
| 01   | 838301 | Main working pump |      | 04   | 865252 | Split flange |  |
| 02   | 865858 | Split flange      |      | 05   | 806120 | Hose         |  |
| 03   | 806142 | Hose              |      |      |        |              |  |




| Ref. | Part     | Description | Qty. | Ref. | Part     | Description |  |
|------|----------|-------------|------|------|----------|-------------|--|
| No.  | No.      |             |      | No.  | No.      |             |  |
| 01   | 838305   | Drive pump  |      | 04   | 8027-222 | ADAP        |  |
| 02   | 806143   | Hose        |      | 05   | 806144   | Hose        |  |
| 03   | 8033-230 | ADAP        |      |      |          |             |  |




| Ref. | Part   | Description                               | Qty. | Ref. | Part   | Description                      |  |
|------|--------|-------------------------------------------|------|------|--------|----------------------------------|--|
| No.  | No.    |                                           |      | No.  | No.    |                                  |  |
| 01   | 838206 | Electric gear select valve 24v (Assembly) |      | 03   | 861818 | ADAP                             |  |
| 01   | 838207 | Electric gear select valve 12v (Assembly) |      | 04   | 806145 | Hose                             |  |
| 02   | 838210 | Valve Solenoid coil (24V)                 |      | 05   | 838213 | Electric gear select valve spool |  |
| 02   | 838211 | Valve Solenoid coil (12V)                 |      |      |        |                                  |  |






| Ref. | Part   | Description        | Qty. | Ref. | Part   | Description      |  |
|------|--------|--------------------|------|------|--------|------------------|--|
| No.  | No.    |                    |      | No.  | No.    |                  |  |
| 01   | 807001 | Parking brake drum |      | 03   | 808129 | Hand brake cable |  |
| 02   | 807002 | Parking brake pad  |      |      |        |                  |  |




| Ref. | Part   | Description                            | Qty. | Ref. | Part     | Description |  |
|------|--------|----------------------------------------|------|------|----------|-------------|--|
| No.  | No.    |                                        |      | No.  | No.      |             |  |
| 01   | 838312 | Transmission reducing valve (Assembly) |      | 04   | 8627-236 | ADAP        |  |
| 02   | 838313 | Transmission reducing valve block      |      | 05   | 806146   | Hose        |  |
| 03   | 838136 | Transmission oil temperature sensor    |      |      |          |             |  |







| Ref. | Part   | Description     | Qty. | Ref. | Part       | Description |  |
|------|--------|-----------------|------|------|------------|-------------|--|
| No.  | No.    |                 |      | No.  | No.        |             |  |
| 01   | 838314 | Oil inlet valve |      | 05   | 8627-218   | ADAP        |  |
| 02   | 806147 | Hose            |      | 06   | 8010-11011 | ADAP        |  |
| 03   | 861818 | ADAP            |      | 07   | 806148     | Hose        |  |
| 04   | 806144 | Hose            |      |      |            |             |  |




| Ref. | Part   | Description                       | Qty. | Ref. | Part   | Description |  |
|------|--------|-----------------------------------|------|------|--------|-------------|--|
| No.  | No.    |                                   |      | No.  | No.    |             |  |
| 01   | 838315 | Transmission air evacuation valve |      | 03   | 873818 | ADAP        |  |
| 02   | 808033 | Transmission boiling oil tank     |      | 04   | 806149 | Hose        |  |




| Ref. | Part      | Description | Qty. | Ref. | Part   | Description |  |
|------|-----------|-------------|------|------|--------|-------------|--|
| No.  | No.       |             |      | No.  | No.    |             |  |
| 01   | 7868BC-36 | T- Junction |      | 04   | 806151 | Hose        |  |
| 02   | 806150    | Hose        |      | 05   | 806152 | ADAP        |  |
| 03   | 864836    | ADAP        |      | 06   | 806153 | Filler cap  |  |



| Ref. | Part   | Description                  | Qty. | Ref. | Part | Description |  |
|------|--------|------------------------------|------|------|------|-------------|--|
| No.  | No.    |                              |      | No.  | No.  |             |  |
| 01   | 806154 | Transmission oil return pipe |      |      |      |             |  |
| 02   | 806155 | Hose                         |      |      |      |             |  |




| Ref.<br>No. | Part<br>No. | Description             | Qty. | Ref.<br>No. | Part<br>No. | Description          |  |
|-------------|-------------|-------------------------|------|-------------|-------------|----------------------|--|
| 01          | 807003      | Converter shell         |      | 15          | 807017      | "O" - ring           |  |
| 02          | 807004      | Gear                    |      | 16          | 807018      | Locating bushing     |  |
| 03          | 807005      | Snap ring               |      | 17          | 807019      | Bearing              |  |
| 04          | 807006      | Bearing                 |      | 18          | 807020      | Snap ring            |  |
| 05          | 807007      | Oil seal                |      | 19          | 807021      | Stator vane          |  |
| 06          | 807008      | Converter Shaft         |      | 20          | 807022      | Snap ring            |  |
| 07          | 807009      | Stator shell seal       |      | 21          | 807023      | Turbine hub          |  |
| 08          | 807010      | Bushing                 |      | 22          | 807024      | Turbine              |  |
| 09          | 807011      | Stator shell            |      | 23          | 807025      | Bearing              |  |
| 10          | 807012      | Oil seal                |      | 24          | 807026      | Snap ring            |  |
| 11          | 807013      | "O" - ring              |      | 25          | 807027      | "O" - ring           |  |
| 12          | 807014      | Oil seal                |      | 26          | 807028      | Impeller shell       |  |
| 13          | 807015      | Converter connect shell |      | 27          | 807029      | Elastic plate        |  |
| 14          | 807016      | Impeller                |      | 28          | 807030      | Elastic plate filler |  |




| Ref.<br>No. | Part<br>No. | Description               | Qty. | Ref.<br>No. | Part<br>No. | Description                 |  |
|-------------|-------------|---------------------------|------|-------------|-------------|-----------------------------|--|
| 01          | 807031      | Gear Box shell            |      | 13          | 807043      | Bearing                     |  |
| 02          | 807032      | Nut                       |      | 14          | 807044      | Oil leveler inspection tube |  |
| 03          | 807033      | Front output flange       |      | 15          | 807045      | Front input shaft cover     |  |
| 04          | 807034      | Oil seal                  |      | 16          | 807046      | Gasket                      |  |
| 05          | 807035      | Bearing seat              |      | 17          | 807047      | Bearing                     |  |
| 06          | 807036      | Gasket                    |      | 18          | 807048      | Bushing                     |  |
| 07          | 807037      | "O" - ring                |      | 19          | 807049      | Input shaft                 |  |
| 08          | 807038      | Bearing                   |      | 20          | 807050      | Gear                        |  |
| 09          | 807039      | Output shaft              |      | 21          | 807051      | Gear                        |  |
| 10          | 807040      | Output shaft Bushing      |      | 22          | 807052      | Bushing                     |  |
| 11          | 807041      | Gear                      |      | 23          | 807053      | Bearing                     |  |
| 12          | 807042      | Rear output shaft bushing |      | 24          | 807054      | Revers clutch shell         |  |






| Ref. | Part   | Description        | Qty. | Ref. | Part   | Description             |  |
|------|--------|--------------------|------|------|--------|-------------------------|--|
| No.  | No.    |                    |      | No.  | No.    |                         |  |
| 25   | 807055 | Drive clutch shell |      | 36   | 807066 | Rear input shaft cover  |  |
| 26   | 807056 | "O" - ring         |      | 37   | 807067 | "O" - ring              |  |
| 27   | 807057 | Bushing            |      | 38   | 807068 | Reverse clutch assembly |  |
| 28   | 807058 | Bushing            |      | 39   | 807069 | Drive clutch assembly   |  |
| 29   | 807059 | Gasket             |      | 40   | 807070 | "O" - ring              |  |
| 30   | 807060 | "O" - ring         |      | 41   | 807071 | Second gear oil pipe    |  |
| 31   | 807061 | Gasket             |      | 42   | 807072 | Derive oil pipe         |  |
| 32   | 807062 | Bearing seat       |      | 43   | 807073 | Revers oil pipe         |  |
| 33   | 807063 | Bearing            |      | 44   | 807074 | First gear oil pipe     |  |
| 34   | 807064 | Rear output flange |      |      |        |                         |  |
| 35   | 807065 | Nut                |      |      |        |                         |  |







| Ref. | Part   | Description  | Qty. | Ref. | Part   | Description     |  |
|------|--------|--------------|------|------|--------|-----------------|--|
| No.  | No.    |              |      | No.  | No.    |                 |  |
| 01   | 807075 | Bearing      |      | 15   | 807089 | Snap ring       |  |
| 02   | 807076 | Washer       |      | 16   | 807090 | Check seat      |  |
| 03   | 807077 | Snap ring    |      | 17   | 807091 | Steel ball      |  |
| 04   | 807078 | Bearing      |      | 18   | 807092 | Thread plug     |  |
| 05   | 807079 | Snap ring    |      | 19   | 807093 | Spring          |  |
| 06   | 807080 | Gear         |      | 20   | 807094 | Spring retainer |  |
| 07   | 807081 | "O" - ring   |      | 21   | 807095 | Bearing         |  |
| 08   | 807082 | Gear bushing |      | 22   | 807096 | Snap ring       |  |
| 09   | 807083 | Piston       |      | 23   | 807097 | Snap ring       |  |
| 10   | 807084 | Oil seal     |      | 24   | 807098 | Gear            |  |
| 11   | 807085 | "O" - ring   |      | 25   | 807099 | Bushing         |  |
| 12   | 807086 | Outer disc   |      | 26   | 807100 | Oil Seal        |  |
| 13   | 807087 | Inner disc   |      | 27   | 807101 | Clutch shaft    |  |
| 14   | 807088 | End disc     |      |      |        |                 |  |




| Ref. | Part   | Description  | Qty. | Ref. | Part   | Description     |  |
|------|--------|--------------|------|------|--------|-----------------|--|
| No.  | No.    |              |      | No.  | No.    |                 |  |
| 01   | 807102 | Bearing      |      | 15   | 807116 | End disc        |  |
| 02   | 807103 | Washer       |      | 16   | 807117 | Snap ring       |  |
| 03   | 807104 | Snap ring    |      | 17   | 807118 | Clutch shaft    |  |
| 04   | 807105 | Bearing      |      | 18   | 807119 | Thread plug     |  |
| 05   | 807106 | Snap ring    |      | 19   | 807120 | Spring          |  |
| 06   | 807107 | Gear         |      | 20   | 807121 | Spring retainer |  |
| 07   | 807108 | Gear bushing |      | 21   | 807122 | Snap ring       |  |
| 08   | 807109 | Piston       |      | 22   | 807123 | Bearing         |  |
| 09   | 807110 | Check seat   |      | 23   | 807124 | Bushing         |  |
| 10   | 807111 | Steel ball   |      | 24   | 807125 | Snap ring       |  |
| 11   | 807112 | Oil seal     |      | 25   | 807126 | Gear            |  |
| 12   | 807113 | "O" - ring   |      | 26   | 807127 | Bushing         |  |
| 13   | 807114 | Outer disc   |      | 27   | 807128 | Oil seal        |  |
| 14   | 807115 | Inner disc   |      |      |        |                 |  |



| Ref. | Part    | Description       | Qty. | Ref. | Part | Description |  |
|------|---------|-------------------|------|------|------|-------------|--|
| No.  | No.     |                   |      | No.  | No.  |             |  |
| 01   | 8117002 | Radiator assembly |      |      |      |             |  |
|      |         |                   |      |      |      |             |  |




| Ref. | Part    | Description               | Qty. | Ref. | Part    | Description           |  |
|------|---------|---------------------------|------|------|---------|-----------------------|--|
| No.  | No.     |                           |      | No.  | No.     |                       |  |
| 01   | 8117003 | Fan shroud                |      | 07   | 8117009 | Radiator cap          |  |
| 02   | 8117004 | Working oil radiator      |      | 08   | 8117010 | Upper Water chamber   |  |
| 03   | 8117005 | Hose clamp                |      | 09   | 8117011 | Radiator seal         |  |
| 04   | 8117006 | Engine upper hose         |      | 10   | 8117012 | Engine water radiator |  |
| 05   | 8117007 | Transmission oil radiator |      | 11   | 8117013 | Radiator frame        |  |
| 06   | 8117008 | Hose clamp                |      | 12   | 8117014 | Radiator bracket      |  |




| Ref. | Part    | Description          | Qty. | Ref. | Part   | Description |  |
|------|---------|----------------------|------|------|--------|-------------|--|
| No.  | No.     |                      |      | No.  | No.    |             |  |
| 13   | 8117015 | Bottom Water chamber |      | 19   | 806168 | Hose        |  |
| 14   | 8117016 | Water drain screw    |      | 20   | 806146 | Hose        |  |
| 15   | 8117017 | Engine bottom hose 1 |      | 21   | 806169 | Hose        |  |
| 16   | 8117018 | Engine bottom hose 2 |      |      |        |             |  |
| 17   | 8117019 | Water hose joint     |      |      |        |             |  |
| 18   | 806155  | Hose                 |      |      |        |             |  |






| Ref. | Part   | Description                     | Qty. | Ref. | Part   | Description                  |  |
|------|--------|---------------------------------|------|------|--------|------------------------------|--|
| No.  | No.    |                                 |      | No.  | No.    |                              |  |
| 01   | 858001 | Air compressor assembly         |      | 07   | 858003 | Air pressure unloading valve |  |
| 02   | 806170 | Air condition compressor V belt |      | 08   | 806172 | Hose                         |  |
| 03   | 806171 | Air compressor V belt           |      | 09   | 862218 | ADAP                         |  |
| 04   | 808034 | Engine right side bracket       |      | 10   | 806173 | Hose                         |  |
| 05   | 806106 | Rubber block                    |      | 11   | 806174 | Hose                         |  |
| 06   | 862218 | ADAP                            |      | 12   | 858004 | Hose clamp                   |  |




| Ref. | Part   | Description              | Qty. | Ref. | Part    | Description               |  |
|------|--------|--------------------------|------|------|---------|---------------------------|--|
| No.  | No.    |                          |      | No.  | No.     |                           |  |
| 13   | 858005 | Hose clamp               |      | 20   | 806178  | Engine water pump V belt  |  |
| 14   | 806175 | Air hose                 |      | 21   | 808035  | Engine left side bracket  |  |
| 15   | 858006 | Stainless Air hose Joint |      | 22   | 806179  | Air compressor inlet hose |  |
| 16   | 806176 | Air hose                 |      | 23   | 806180  | Hose                      |  |
| 17   | 808007 | Stainless Air hose Joint |      | 24   | 8117020 | Engine Fan                |  |
| 18   | 806177 | Air hose                 |      | 25   | 838139  | Starting relay            |  |
| 19   | 858007 | Hose clamp               |      | 26   | 838140  | Engine preheating relay   |  |






| Ref. | Part   | Description                            | Qty. | Ref. | Part | Description |  |
|------|--------|----------------------------------------|------|------|------|-------------|--|
| No.  | No.    |                                        |      | No.  | No.  |             |  |
| 01   | 838134 | Engine flame-out motor (Assembly part) |      |      |      |             |  |
|      |        |                                        |      |      |      |             |  |




| Ref. | Part   | Description               | Qty. | Ref. | Part   | Description               |  |
|------|--------|---------------------------|------|------|--------|---------------------------|--|
| No.  | No.    |                           |      | No.  | No.    |                           |  |
| 01   | 807129 | Rear Transmission shaft   |      | 03   | 807131 | Front Transmission shaft  |  |
| 02   | 807130 | Middle Transmission shaft |      | 04   | 807132 | Transmission shaft bridge |  |



| Ref. | Part   | Description                        | Qty. | Ref. | Part   | Description                      |  |
|------|--------|------------------------------------|------|------|--------|----------------------------------|--|
| No.  | No.    |                                    |      | No.  | No.    |                                  |  |
| 01   | 807133 | Transmission shaft plate           |      | 04   | 807138 | Middle transmission shaft B part |  |
| 02   | 807134 | Transmission shaft universal joint |      | 03   | 807139 | Rear transmission shaft A part   |  |
| 03   | 807135 | Front transmission shaft A part    |      | 04   | 807140 | Rear transmission shaft B part   |  |
| 04   | 807136 | Front transmission shaft B part    |      |      |        |                                  |  |
| 03   | 807137 | Middle transmission shaft A part   |      |      |        |                                  |  |


## Axle (Front and Rear axle)

TLR6600



| Ref. | Part     | Description              | Qty. | Ref. | Part     | Description     |  |
|------|----------|--------------------------|------|------|----------|-----------------|--|
| No.  | No.      |                          |      | No.  | No.      |                 |  |
| 01   | 8181820  | Bolts                    |      | 08   | 818151-3 | Gear Ring nut   |  |
| 02   | 808202   | Axle end cover           |      | 09   | 808207   | Gear Ring       |  |
| 03   | 808203   | Axle end cover paper pad |      | 10   | 808208   | Gear Ring plate |  |
| 04   | 808204   | Planetary gear assembly  |      | 11   | 808209   | Baffle ring     |  |
| 05   | 808205   | Planetary gear paper pad |      | 12   | 808210   | Bearing         |  |
| 06   | 81818240 | Bolts                    |      | 13   | 818120   | Rim nut         |  |
| 07   | 808206   | Sun gear axle            |      | 14   | 81811026 | Locating pin    |  |


| Ref. | Part     | Description                      | Qty. | Ref. | Part     | Description                      |  |
|------|----------|----------------------------------|------|------|----------|----------------------------------|--|
| No.  | No.      |                                  |      | No.  | No.      |                                  |  |
| 15   | 808211   | Wheel boss                       |      | 35   | 808229   | Bearing                          |  |
| 16   | 808212   | Wheel bolts                      |      | 36   | 808200R  | Rear axle case                   |  |
| 17   | 81811245 | Bolts                            |      | 36   | 808200F  | Front axle case                  |  |
| 18R  | 808213   | Axle brake assembly Right side   |      | 37   | 808230   | air evacuation valve             |  |
| 18L  | 808214   | Axle brake assembly Left side    |      | 38   | 806181   | Compound gasket                  |  |
| 19   | 808215   | Bearing                          |      | 39   | 2300129  | Magnet screwed plug              |  |
| 20   | 808216   | Framework oil seal               |      | 40   | 808231   | Snap ring                        |  |
| 21   | 808217   | Axle hub                         |      | 41   | 808232   | Steering case fork               |  |
| 22   | 808218   | Bearing                          |      | 42   | 808233-A | Bushing                          |  |
| 23   | 808219   | Spacer bush                      |      | 43   | 808234   | Pin                              |  |
| 24   | 808220   | Oil seal                         |      | 44   | 808233-B | Oil cylinder fork                |  |
| 25R  | 808221   | Steering case Right side         |      | 45   | 8181365  | Nut                              |  |
| 25L  | 808222   | Steering case Left side          |      | 46   | 808236   | Steering oil cylinder            |  |
| 26   | 808223   | Steering case plate              |      | 47   | 808237   | Locating pin                     |  |
| 27   | 808224   | Knuckle bearing                  |      | 48   | 81811450 | Bolts                            |  |
| 28   | 808225   | Framework oil seal               |      | 49   | 808238   | Bushing x 2                      |  |
| 29   | 808226   | Articulate Pin adjustable pad    |      | 50   | 808239   | Differential mechanism paper pad |  |
| 30   | 808227   | Articulate Pin                   |      | 51   | 808240   | Differential mechanism assembly  |  |
| 31   | 818101   | M10 Straight type grease fitting |      | 52   | 808241   | Locating pin                     |  |
| 32   | 81811230 | Bolts                            |      | 53   | 81811240 | Bolts                            |  |
| 33   | 808201   | Axle Shaft                       |      | 54   | 808271   | Axle brake air bag               |  |
| 34   | 808228   | Oil seal                         |      | 55   | 808272   | Brake hose right side            |  |
| 56   | 808273   | Brake hose left side             |      | 57   | 808274   | Brake pad                        |  |




| Ref. | Part   | Description         | Qty. | Ref. | Part   | Description                 |  |
|------|--------|---------------------|------|------|--------|-----------------------------|--|
| No.  | No.    |                     |      | No.  | No.    |                             |  |
| 01   | 808242 | Snap ring           |      | 08   | 808249 | "O" - ring                  |  |
| 02   | 808243 | Flange pad          |      | 09   | 808250 | Bearing                     |  |
| 03   | 808244 | Flange              |      | 10   | 808251 | Spacer bush                 |  |
| 04   | 808245 | Bevel gear lock nut |      | 11   | 808252 | Bevel gear pad              |  |
| 05   | 808246 | Framework seal      |      | 12   | 808253 | Bearing                     |  |
| 06   | 808247 | Oil seal retainer   |      | 13   | 808254 | Bevel gear                  |  |
| 07   | 808248 | Steel ball          |      | 14   | 808255 | Differential mechanism case |  |




| Ref. | Part   | Description                | Qty. | Ref. | Part     | Description          |  |
|------|--------|----------------------------|------|------|----------|----------------------|--|
| No.  | No.    |                            |      | No.  | No.      |                      |  |
| 15   | 808256 | Differential mechanism nut |      | 24   | 808265   | Planetary gear       |  |
| 16   | 808257 | Bearing                    |      | 25   | 808266   | Differential carrier |  |
| 17   | 808258 | Main gear                  |      | 26   | 81811225 | Bolt                 |  |
| 18   | 808259 | Axle shaft gear pad        |      | 27   | 81811220 | Bolt                 |  |
| 19   | 808260 | Axle shaft gear            |      | 28   | 808267   | Lock pad 1           |  |
| 20   | 808261 | Planetary gear pad         |      | 29   | 808268   | Lock pad 2           |  |
| 21   | 808262 | Planetary gear             |      | 30   | 808269   | Locating pin         |  |
| 22   | 808263 | Planetary gear pin         |      | 31   | 808270   | Bearing cap          |  |
| 23   | 808264 | Locating pin               |      | 32   | 81811270 | Bolt                 |  |




| Ref. | Part   | Description                                       | Qty. | Ref. | Part | Description |  |
|------|--------|---------------------------------------------------|------|------|------|-------------|--|
| No.  | No.    |                                                   |      | No.  | No.  |             |  |
| 01   | 808280 | Rim assembly                                      |      |      |      |             |  |
| 02   | 808281 | Standard tyre (With inner tube and tire liner)    |      |      |      |             |  |
| 03   | 808282 | Herringbone tire (With inner tube and tire liner) |      |      |      |             |  |
| 04   | 808282 | Solid tire with rim                               |      |      |      |             |  |
|      |        |                                                   |      |      |      |             |  |




| Ref. | Part   | Description                        | Qty. | Ref. | Part   | Description |  |
|------|--------|------------------------------------|------|------|--------|-------------|--|
| No.  | No.    |                                    |      | No.  | No.    |             |  |
| 01   | 818300 | Lifting cylinder assembly          |      | 04   | 806162 | Hose        |  |
| 02   | 838137 | Oil pressure sensor (Option part)  |      | 05   | 806157 | Hose        |  |
| 03   | 838138 | Moment limiter cable (Option part) |      |      |        |             |  |



| Ref. | Part   | Description                      | Qty. | Ref. | Part   | Description                     |  |
|------|--------|----------------------------------|------|------|--------|---------------------------------|--|
| No.  | No.    |                                  |      | No.  | No.    |                                 |  |
| 01   | 818301 | Cylinder tube weldment           |      | 07   | 818307 | Nut                             |  |
| 02   | 838361 | Cylinder valve                   |      | 08   | 818305 | Bushing (Rod end)               |  |
| 03   | 818302 | Bushing (Base end)               |      | 09   | 818306 | Rod weldment                    |  |
| 04   | 818101 | M10 Straight type grease fitting |      | 10   | 860101 | Lifting cylinder seal kit (set) |  |
| 05   | 818303 | Head gland                       |      |      |        |                                 |  |
| 06   | 818304 | Cylinder piston                  |      |      |        |                                 |  |




| Ref. | Part   | Description              | Qty. | Ref. | Part | Description |  |
|------|--------|--------------------------|------|------|------|-------------|--|
| No.  | No.    |                          |      | No.  | No.  |             |  |
| 01   | 818310 | Extend cylinder assembly |      |      |      |             |  |
| 02   | 806158 | Hose                     |      |      |      |             |  |
| 03   | 806161 | Hose                     |      |      |      |             |  |




| Ref. | Part   | Description                      | Qty. | Ref. | Part   | Description                    |  |
|------|--------|----------------------------------|------|------|--------|--------------------------------|--|
| No.  | No.    |                                  |      | No.  | No.    |                                |  |
| 01   | 818311 | Cylinder tube weldment           |      | 06   | 818314 | Cylinder piston                |  |
| 02   | 838361 | Cylinder valve                   |      | 07   | 818317 | Nut                            |  |
| 03   | 818312 | Bushing (Base end)               |      | 08   | 818315 | Bushing (Rod end)              |  |
| 04   | 818101 | M10 Straight type grease fitting |      | 09   | 818316 | Rod weldment                   |  |
| 05   | 818313 | Head gland                       |      | 10   | 860102 | Extend cylinder seal kit (set) |  |







| Ref. | Part   | Description            | Qty. | Ref. | Part | Description |  |
|------|--------|------------------------|------|------|------|-------------|--|
| No.  | No.    |                        |      | No.  | No.  |             |  |
| 01   | 818320 | Tilt cylinder assembly |      |      |      |             |  |
| 02   | 806186 | Hose                   |      |      |      |             |  |
| 03   | 806187 | Hose                   |      |      |      |             |  |




| Ref. | Part   | Description                      | Qty. | Ref. | Part   | Description                  |  |
|------|--------|----------------------------------|------|------|--------|------------------------------|--|
| No.  | No.    |                                  |      | No.  | No.    |                              |  |
| 01   | 818321 | Cylinder tube weldment           |      | 06   | 818324 | Cylinder piston              |  |
| 02   | 838361 | Cylinder valve                   |      | 07   | 818327 | Nut                          |  |
| 03   | 818322 | Bushing (Base end)               |      | 08   | 818325 | Bushing (Rod end)            |  |
| 04   | 818101 | M10 Straight type grease fitting |      | 09   | 818326 | Rod weldment                 |  |
| 05   | 818323 | Head gland                       |      | 10   | 860103 | Tilt cylinder seal kit (set) |  |




| Ref. | Part   | Description             | Qty. | Ref. | Part | Description |  |
|------|--------|-------------------------|------|------|------|-------------|--|
| No.  | No.    |                         |      | No.  | No.  |             |  |
| 01   | 818330 | Slave cylinder assembly |      |      |      |             |  |
| 02   | 806188 | Hose                    |      |      |      |             |  |
| 03   | 806189 | Hose                    |      |      |      |             |  |



| Ref. | Part   | Description                      | Qty. | Ref. | Part   | Description                   |  |
|------|--------|----------------------------------|------|------|--------|-------------------------------|--|
| No.  | No.    |                                  |      | No.  | No.    |                               |  |
| 01   | 818331 | Cylinder tube weldment           |      | 06   | 818334 | Cylinder piston               |  |
| 02   | /      | /                                |      | 07   | 818337 | Nut                           |  |
| 03   | 818332 | Bushing (Base end)               |      | 08   | 818335 | Bushing (Rod end)             |  |
| 04   | 818101 | M10 Straight type grease fitting |      | 09   | 818336 | Rod weldment                  |  |
| 05   | 818333 | Head gland                       |      | 10   | 860104 | Slave cylinder seal kit (set) |  |




| Ref. | Part   | Description                   | Qty. | Ref. | Part   | Description |  |
|------|--------|-------------------------------|------|------|--------|-------------|--|
| No.  | No.    |                               |      | No.  | No.    |             |  |
| 01   | 818340 | Quick hitch cylinder assembly |      | 04   | 806191 | Hose        |  |
| 02   | 861618 | ADAP                          |      |      |        |             |  |
| 03   | 806190 | Hose                          |      |      |        |             |  |




| Ref. | Part   | Description                                                | Qty. | Ref. | Part   | Description                                                |  |
|------|--------|------------------------------------------------------------|------|------|--------|------------------------------------------------------------|--|
| No.  | No.    |                                                            |      | No.  | No.    |                                                            |  |
| 01   | 818341 | Cylinder tube weldment                                     |      | 06   | 818346 | Nut                                                        |  |
| 02   | 818342 | Quick hitch cylinder lock pin<br>standard quick hitch only |      | 07   | 860105 | Quick hitch cylinder seal kit<br>(set)                     |  |
| 03   | 818343 | Head gland                                                 |      | 02   | 818347 | D type Quick hitch lock pin<br>For D type Quick hitch only |  |
| 04   | 818344 | Cylinder Rod                                               |      |      |        |                                                            |  |
| 05   | 818345 | Cylinder piston                                            |      |      |        |                                                            |  |







| Ref. | Part   | Description              | Qty. | Ref. | Part   | Description |  |
|------|--------|--------------------------|------|------|--------|-------------|--|
| No.  | No.    |                          |      | No.  | No.    |             |  |
| 01   | 8618-1 | Quick joint part male    |      | 06   | 806193 | Hose        |  |
| 02   | 861818 | ADAP                     |      | 07   | 806191 | Hose        |  |
| 03   | 838362 | Quick Joint switch Valve |      | 08   | 806190 | Hose        |  |
| 04   | 838363 | T block                  |      |      |        |             |  |
| 05   | 806192 | Hose                     |      |      |        |             |  |




| Ref. | Part   | Description         | Qty. | Ref. | Part   | Description               |  |
|------|--------|---------------------|------|------|--------|---------------------------|--|
| No.  | No.    |                     |      | No.  | No.    |                           |  |
| 01   | 808040 | Boom outer weldment |      | 05   | 806195 | Wear plate 220            |  |
| 02   | 808041 | Bushing             |      | 06   | 808043 | Adjusting shim 380        |  |
| 03   | 806194 | Wear plate 380      |      | 07   | 838141 | Boom LED light Right side |  |
| 04   | 808042 | Adjusting shim 220  |      | 08   | 838142 | Boom LED light Left side  |  |




| Ref. | Part   | Description         | Qty. | Ref. | Part   | Description  |  |
|------|--------|---------------------|------|------|--------|--------------|--|
| No.  | No.    |                     |      | No.  | No.    |              |  |
| 01   | 808050 | Boom inner weldment |      | 07   | 806196 | Wear plate A |  |
| 02   | 808051 | Bushing             |      | 08   | 808052 | U-Track      |  |
| 03   | 806194 | Wear plate 380      |      | 09   | 806196 | Wear plate B |  |
| 04   | 808043 | Adjusting shim 380  |      | 10   | 808053 | Iron pipe L  |  |
| 05   | 806195 | Wear plate 220      |      | 11   | 808054 | Iron pipe S  |  |
| 06   | 808042 | Adjusting shim 220  |      |      |        |              |  |




| Ref. | Part   | Description                   | Qty. | Ref. | Part | Description |  |
|------|--------|-------------------------------|------|------|------|-------------|--|
| No.  | No.    |                               |      | No.  | No.  |             |  |
| 01   | 808060 | Standard quick hitch weldment |      |      |      |             |  |
| 02   | 808061 | Quick hitch cylinder cover    |      |      |      |             |  |
|      |        |                               |      |      |      |             |  |



| Ref. | Part   | Description                 | Qty. | Ref. | Part | Description |  |
|------|--------|-----------------------------|------|------|------|-------------|--|
| No.  | No.    |                             |      | No.  | No.  |             |  |
| 01   | 808070 | D type quick hitch weldment |      |      |      |             |  |
|      |        |                             |      |      |      |             |  |
|      |        |                             |      |      |      |             |  |




| Ref. | Part   | Description                    | Qty. | Ref. | Part   | Description             |  |
|------|--------|--------------------------------|------|------|--------|-------------------------|--|
| No.  | No.    |                                |      | No.  | No.    |                         |  |
| 01   | 858008 | Air bag weldment               |      | 04   | 806109 | Rear air pressure hose  |  |
| 02   | 858009 | Air bag water drain valve      |      | 05   | 806197 | Air pressure brake hose |  |
| 03   | 858010 | Air bag pressure release valve |      | 06   | 806198 | Air pressure brake hose |  |




| Ref. | Part   | Description          | Qty. | Ref. | Part   | Description      |  |
|------|--------|----------------------|------|------|--------|------------------|--|
| No.  | No.    |                      |      | No.  | No.    |                  |  |
| 01   | 808036 | Front mirror bracket |      | 04   | 808115 | Rear view mirror |  |
| 02   | 808037 | Rear mirror bracket  |      | 05   | 806199 | Rubber plug      |  |
| 03   | 808136 | Convex mirror        |      |      |        |                  |  |






| Ref. | Part   | Description        | Qty. | Ref. | Part   | Description       |  |
|------|--------|--------------------|------|------|--------|-------------------|--|
| No.  | No.    |                    |      | No.  | No.    |                   |  |
| 01   | 808038 | Front bracket      |      | 04   | 806200 | Splash guard      |  |
| 02   | 808039 | Rear right bracket |      | 05   | 806201 | Splash guard clip |  |
| 03   | 808040 | Rear left bracket  |      |      |        |                   |  |



| Ref. | Part    | Description                      | Qty. | Ref. | Part   | Description                      |  |
|------|---------|----------------------------------|------|------|--------|----------------------------------|--|
| No.  | No.     |                                  |      | No.  | No.    |                                  |  |
| 01   | 8080411 | Muffler For Yunei & Yuchai       |      | 05   | 808043 | Muffler clip                     |  |
| 02   | 806202  | Muffler gasket                   |      | 06   | 808044 | Muffler clip bracket             |  |
| 03   | 808059  | Muffler tube weldment For Yunnei |      | 07   | 808045 | Muffler bracket                  |  |
| 04   | 806203  | Muffler gasket                   |      | 08   | 808046 | Muffler tube weldment for Yuchai |  |



| Ref. | Part   | Description                       | Qty. | Ref. | Part   | Description          |  |
|------|--------|-----------------------------------|------|------|--------|----------------------|--|
| No.  | No.    |                                   |      | No.  | No.    |                      |  |
| 01   | 808047 | Muffler for CUMMINS engine        |      | 04   | 806205 | Muffler gasket       |  |
| 02   | 808058 | Muffler tube weldment for cummins |      | 05   | 808049 | Muffler clip         |  |
| 03   | 806204 | Muffler gasket                    |      | 06   | 808050 | Muffler clip bracket |  |

